

Wall Pad with Lip Top and Bottom Installation instructions

1. Layout all the pads to assure correct number and where odd size panels go. If cut-out pads are applicable, check fit and those pads will go up first. Determine height above finished floor. Example: The pads are six inches in height and you want to install four inches above the floor to allow for tile molding. The top of the pad will be at 76 inches.
2. In this case, mark 76 inches from the floor in two locations and snap a chalk line between the two marks. Making sure that the line is level using bubble level, etc.
3. Hold the wall pad to the established line and install with the appropriate fastener for your wall type through the top one-inch lip. Plumb the pads vertically to insure squareness. Pads are fastened similarly at the bottom. Four fasteners per pad (two at top, two at bottom) should be sufficient to hold pad in place under normal conditions. Using nickel plated finish washers will provide a more finished appearance and curtail “twisting” of the vinyl by the head of the fastener.
4. Install “cutout” panels and column pads first (if applicable) then move out to ends of walls. When adjacent to doors, allow one-inch minimum spacing from edge of door. Plumb vertically and horizontally first and every panel.

Tapcon is a registered trademark of Illinois Tool Works.

Use in: Concrete, block, brick.

Use with: Nickel Finish Washer #14 prevents vinyl from twisting under the screw head.

Made of: Case hardened carbon steel, zinc chromate finish (ATSM B633).

Recommended Size: 1/4 inch x 1 3/4 inch length, Flat Head/Phillips

